

PROVISIONS 84 DTHERS

SCENERAL_* $\frac{HDISTWAY}{HDISTWAY}$ MUST BE IN ACCORDANCE WITH SAFETY CODE FOR ELEVATORS (ASME A17.1 DR B44-2000) AND ALL STATE/PROVINCIAL AND LOCAL CODES.

PLUMB HOISTWAY— DUE TO CLOSE RUNNING CLEARANCES DIVNER/AGENT MUST ENSURE THAT HOISTWAY AND PIT (WHERE PROVIDED) ARE LEYEL, PLUMB AND SQUARE AND ARE IN ACCORDANCE WITH THE DIMENSIONS ON THESE DRAWINGS.

CONSTRUCTION SITE— DWER/AGENT TO PROVIDE ALL MASDINRY, CAPPENTRY AND DRYVALL VORK AS REQUIRED AND SHALL PATCH AND MAKE GOOD CINCLUDING FINISH PAINTING ALL AREAS WHERE WALLS/FLORIS MAY REQUIRE TO BE CUT, DRILLED DR ALTERED IN ANY WAY TO PERMIT THE PROPER INSTALLATION OF THE LIFT.

DIMENSIONS
CONTRACTOR/COUSTOMER TO VERIFY ALL DIMENSIONS AND REPORT ANY DISCREPANCIES TO DUR OFFICE IMMEDIATELY.

ELODR/SUPPORT WALL LOADS:— STRUCTURAL ENGINEER TO ASSURE THAT BUILDING AND SHAFT WILL SAFELY SUPPORT ALL LOADS IMPOSED BY THE LIFT EQUIPMENT. REFER TO THE TABLES ON THIS DRAWING FOR LOADS IMPOSED BY THE EQUIPMENT.

<u>DOORS-</u> SUITABLE LINTELS MUST BE PROVIDED BY OWNER/AGENT DOOR FRAMES ARE NOT DESIGNED TO SUPPORT OVERHEAD WALL

LICATION / ACCESS- MACHINE ROOM LICATED AT THE LIVEST LEVEL ADJACENT TO HOISTWAY, UNLESS SHOWN OTHERVISE ON THE LAYOUT DRAWINGS, FIELD ADJUSTMENT BY INSTALLER MAY BE CREESSARY TO MEET JOB SITE CONDITIONS OR REGULATIONS. ACCES TO MACHINE ROOM TO BE THROUGH A SELF CLOSING AND SELF LICKING DOOR. ACCESS

S<u>JEEVES FOR DIL & FLECTRIC LINES-</u> PROVIDED BY DTHERS, FROM MACHINE ROOM TO HOISTVAY. (POSITION PER INSTALLERS INSTRUCTIONS).

	15		115/1PH	LIGHTS
21	50	60	230/1PH/60HTZ	
15.6	30	30	INFO 208/3PH/60HTZ	R INFO
CURRENT (AMPS)	FUSE (AMPS) CURREN	SIZE (AMPS)	(V/PH/CYCLE)	
FULL LOAD	TIME DELAY	DISCONNECT	INPUT VOLTAGE	

POWER SUPPLY— (SEE SPECIFICATIONS) LOCKABLE FUSED DISCONNECT VITH AUXILLARY CONTACT TO BRACE THE BATTERY FEED IN CIRCUIT BREAKERS WITH A 3-POILE BREAKER FOR BATTERY FEED REQUIRED, IN COMPLIANCE WITH ELECTRICAL CODE, AS FOLLIUS (LOCATED ON WALL ON LOCK JAMB SIDE OF MACHINE RODM DODR)

FASCIA PANEL BLIDY UPPER LEVEL ENTRANCE— WHERE REQUIRED, FASCIA PANEL MUST BE FASTENED TO A SOLID WALL AND BE PERPENDICULAR TO THE FLOOR AND WALLS, HOISTWAY FASCIA IS NOT SELF-SUPPORTING FOR LONG, CONTINUOUS RINS VOID OF ENTRANCES, ADEQUATE SUPPORT AND THE FASCIA MUST BE PROVIDED BY OTHERS.

RETURN WALLS- RETURN WALLS AT ENTRANCES MUST BE BUILT-IN BY DITHERS AFTER ENTRANCE ASSEMBLIES ARE IN PLACE. ENTRANCE ASSEMBLY MUST BE SECURELY FASTENED TO WALLS BY ELEVATOR CONTRACTOR. ENTRANCE ASSEMBLIES— ENTRANCE ASSEMBLIES MUST BE ADJUSTED TO ALIGN WITH PLATFORM AND INTERLOCK EQUIPMENT. OTHERS TO ALLOV AN ADEQUATE ROUGH OPENING.

REV-000

LU/LA ORION MODEL 4260W